

User Manual


Vividia® F8 Inspection DVR Flashlight

Features

- Video & audio recording
- Video size: HD 1280x720 , VGA 640x480 pixels
- 1.5" TFT LCD resolution 480x240
- MRemory :support Micro SDHC (class 6 or above)
- Battery : Li-ion rechargeable battery (3.7 V / **4400** mAh)
- High Power LEDx3 PCS

Outlooks & Keys Function





Operation:

Inserting battery & micro SD card (class 6 or above)

Before using you 'should better' make sure that there is a battery in the battery room, if there are no battery, and you need to put one in, please keep the positive electrode on the up side. Install battery and battery cover, then you can start to use the light.

Before using the camera or a video function micro SD card must be inserted into the card slot

Note: card must be inserted with contacts upwards.

1. Transferring files to a computer

Connect USB cable between the unit output and computer


Switch on the unit, computer will detect unit as removable disk

Files can now be copied over to computer as required



2. Battery Charging

Before charging ensure the unit is switched off. It cannot be operated whilst being charged.
Charging from AC adapter or computer USB port.



Connect one end of the USB lead to PC and the other end to the devices mini USB port , During charging the Power indicator will illuminate red,
When charging is complete the power indicator will go out, this can take up **longer than 8** hours.

Special remind :When the battery is take out ,there are approx 10 minutes for you to put another back ,otherwise the setting of date and time will disappear, and you must set them ,again.

POWER/MENU: When the power is off, press the button can turn on it, when the power is on press the button more than two second will turn it off. And when it's on, press 0.5 second , the menu will appear, if you press again ,menu will disappear.。

LEFT: (1) When the power is on, press the button can take a picture, press one second can do digital zoom 1X-4X.。

(2) When the menu appear, press the button 0.5 second can turn the direction UP.

RIGHT: (1) When the power is on press the button will start recording, press again will stop recording.。

(2) When the menu appear, press the button 0.5 second can turn the direction DOWN.。

(3) When the menu appear, press one second will confirm the menu option.。

LED LAMP: This button is only for LED, press the button will change the state of light, there are five kinds of light, the order is Dim→Medium→Strong →Flash →SOS

Life of full charged battery

Status	Life time (LED alone)	(LED & LCD screen on)
Dim (10%)	500 min (around)	400 min (around)
Medium (30%)	250 min (around)	210 min (around)
Strong (100%)	200 min (around)	180 min (around)
Flash	over 15 hours	over 10 hours
SOS	over 20 hours	over 13 hours

* Press and hold LED LAMP for 2 seconds to turn off the light directly

* When using light only, Green LED would flash for 5 seconds and then the light would be turn off directly if battery is low

Switching On/Off

Camera & Video Operation

BEFORE USING THE UNIT FOR THE FIRST TIME:


Ensure the time and date have been set

Ensure the micro SD card is inserted



Press the Power button to switch the device on.

The camera image will appear on the screen and the Power indicator will illuminate green





To switch the device off , press the ON/OFF button 2 seconds

Inserting micro SD card

Before using the camera or video function an micro SD card must be inserted into the card slot

Press the Left button to take a picture,
press 1 second to change zoom ratio
Press the Right button to take a video



Menu Options The menu options are accessed by pressing the POWER/MENU button

To change tag press LEFT key 1 second To move up/down the menu press LEFT/RIGHT keys

To enter function press RIGHT key 1 second

Playback Mode

To enter Playback Mode the latest stored picture or video will be displayed.




Video Playback →




Image Playback →



Use the navigation key  to select playback (video file will auto play)
Press OK key to stop video playback


Looping Video

To setting looping video On / Off



Underwater Mode

To setting underwater mode On / Off




Setup

To enter setup menu




Setup → **Resolution** → Select video & image resolution HD / VGA



Setup → **Microphone** → Select microphone on /off



Setup → Data → Set Date/Time




Use the navigation keys LEFT/RIGHT to edit the time and date (YY/MM/DD, MM/DD/YY, DD/MM/YY)

Setup → Language


Language Selection

Allows the language to be set for the menu functions.

Use the navigation keys LEFT/RIGHT to select from the languages available




Setup → Default Setting



Select "OK" camera will reset to default setting

Setup → Format



Select "OK" format all data on the micro SD card; Select "Cancel" exit without formatting

Specification

- . High Power LED x 3 PCS flashlight supports lighting & recording in dark area
- . Built in 480*240, 1.5" TFT LCD
- . AV recorder & camera , Waterproof (IP67)
- . Supports Media Card : Micro SDHC class 6 or above (supported up to 32 GB)
- . Powered by embedded rechargeable battery (included)
- . 1/4" CMOS HD (1280*720) image sensor
- Focusing Range : 80 cm to infinity
- . Image resolution : 5M(2592*1944), 3M(2048*1536), 1M (1280*720), VGA (640*480)
- . Movie size : 1280*720 (HD), 640*480 (VGA), Frame Rate:30 fps
- . Power Led lighting luminous flux over 1000 luminous
- . Operating Temperature: 0°C (0%) to 50°C (RH60%)
- . Storage Temperature: -10°C (0%) to 55°C (RH90%)
- . USB cable: for data transmission and battery charge (included)
- . Overall Dimension: Ø55 x 225 mm

Special remind : After using in the sea, please rinse with water and then dried, it can lengthen the service life.

Vividia Technologies

3110 Wade Hampton Blvd. #18
Taylors, SC 29650
www.oasisscientific.com